


Setting Post in Concrete

Steel Post or Perma Post




Steel post or Perma Post Set in Concrete

Use a Spirit level to ensure the post is plumb on both sides.



Sectional View



Concrete Must flow right through both holes in the bottom of the Post.

